

WIRING DIAGRAM FOR PRECISION BASS®



Directions: Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by blue arrows.

250K pots recommended for better tone.
 .022mfd cap recommended

FOR FOLLOWING BASS PICKUPS
 LACE TRANSENSOR
 LACE SENSOR
 ALUMA-P

