


# VARIOUS STANDARD WIRING DIAGRAMS #1




## STANDARD WIRING FOR SINGLE

S-100 / S-150 = out of production  
Transensor  
Lace Sensor




## STANDARD WIRING FOR HUMBUCKER

D -100  
D -150  
Transensor  
Lace Sensor



## STANDARD WIRING FOR HUMBUCKER INTO SINGLE COIL

D -100  
D -150  
Transensor  
Lace Sensor



The Lace Sensor Dually can be Split into single top / both /single bottom by using a SPDT on/off/on Mini Toggle Switch.

